

# Mounting instruction

## ECOFLEX® 10 / AIRCOM PLUS® UHF-Connector / Art. Nr.: 7369



1



Cut off cable tail right-angled.

2



Move the nut, clamping ring and rubber washer over the cable tail. Hint: With a bit of Vaseline the rubber washer can be moved easily over the cable sheath.

3



Remove 17 mm of the outer sheath with a knife.

4



Bend copper braid upwards right-angled. Insert contact sleeve between copper foil and braid until stop. Cut off protruding braid. Move the rubber seal to the front, up to the contact sleeve.

5



Remove the copper foil and the dielectric with a knife.

6



The prepared cable tail has to be carefully inserted into the housing until stop. Tighten the clamping nut finger tight with two open-ended spanners 17/18 mm. A small split should remain

7



Solder inner conductor at the tip carefully.