



This part number complies with RoHS.

Notice: JYEBAO reserves the right to make modifications deemed appropriate.



CABLE ASSEMBLY INSTRUCTION TNC3100-9142 JYE BAO CO., LTD. Α В С **FERRULE BODY** COVER DIAGRAM ASSEMBLY INSTRUCTION Step 1: STRIP AS SHOWN. Step 2: SLIDE FERRULE "A" OVER CABLE. Step 3: WRAP THE BRAIDING UPWARDS. Step 4: SLIDE CENTER CONDUCTOR ON THE CONTACT PIN OF CONNECTOR "B" AND contact pin SOLDER IN "Y". Step 5: SLIDE FERRULE "A" TOWARDS THE CONNECTOR "B" AND CRIMP. Step 6: SCREW "C" ON THE CONNECTOR.

This part number complies with RoHS.

Notice: JYEBAO reserves the right to make modifications deemed appropriate.